Social

Breeze User Manual

Contents

Safety Precautions 3
Overview 4
1. Introduction 5
2. Your Mobile Phone 8
3. Communicate by phone function 9
4. Import Methods 10
5. Function of main menu 10
6.Call center 11
8. Fun&Games 13
10. Multimedia 15
11. Phonebook 16
12. Messaging 17
13.Image Viewer 18
14.Calendar 18
15. Services 18
16. Settings 19
17. Social networks 20
18. SIM card service 21
19. PC connect 22
20. Original accessories 23
21. About the battery 24
22. Maintenance and service 25
23. Important safety directions 26

Safety Precautions

Please read the following precautions carefully, some of them to the rules may lead to be obstruction of some laws.

	Secure startup Do not turn on your phone if it is prohibited to use wireless equipment or any usage thereof may result in interference or hazard.
	Put traffic safety first Abide by all local laws and regulations. Drive your car with both hands. Put traffic safety first!
	Interference Some wireless equipment may be subject to interference, affecting its performance.
	Hospitals Please comply with any related laws. Turn the phone off when you are close to medical centers and equipment.
	Planes Please comply with any related restrictions. Usage of wireless equipment may result in interference to the plane.

	Proper maintenance service Only qualified Social™ technicians are allowed to install or repair the equipment this phone. Any attempt to do so may result in a voided warranty.
	Chargers and batteries Use only Social™ Approved chargers and batteries should be used. Any Damage resulting from using non approved batteries or chargers will result in a voided warranty.
	Waterproofing The phone is not waterproof! Please keep it dry! Water damage is not covered by warranty.
	Backup Be sure to backup your files music, videos, pictured etc.) to a safe location such as a SD Card.

Overview

■ Function Description

This phone is a perfect combination of design and workmanship, with a streamlined case housing a full assortment of features. The FB101 features a full QWERTY keyboard, 2” color LCD screen, 1.3MP camera, Bluetooth, FM radio and much more.

■ Passwords

Phone password

With a phone password you can prevent others from using your mobile phone without your approval. The default phone password is 0000.

PIN

PIN (personal identification number) and UPIN (unique personal identification number) (4-8 digit) help you to prevent others using your SIM card without your approval.

PUK

The 8 digit PUK (personal unlocking key) is used to change the locked PIN and UPIN. If it is not provided with the SIM card, please contact your service provider.

1. Introduction

■ Inserting the SIM card and the Battery

Turn off the Phone and disconnect with the charger before removing SIM card or the battery.

Use the images below to see how the battery and SIM cards should be installed.

NOTE: SIM cards and are vulnerable to scratching or bending. Caution should be taken when insert or removing the card.

Battery:

SIM Cards:

■ Inserting and Removing the SD memory Card

Use approved and compatible SD Memory cards.

1. Turn off the phone, remove the back cover and take out the battery.

2. Slide the SD card clip and unlock it.

3. Lift the clip, and insert the card into it with the side of golden contacts facing inwards.

4. Put down the clip and slide it back to the locked in position.

5. Put in the battery and apply the back cover.

■ Charging the Battery

Only use approved batteries and chargers designed for to the FB 101. Using other types of batteries and chargers will void the warranty.

Refer to Social™ for replacement batteries and chargers.

1. Plug the charger in an AC power socket.

2. Insert the plug contact of the charger into the phone (as shown below).

■ Startup and Shutdown

Press the power key to start up or shut down the mobile phone.

If you are prompted to input a PIN or UPIN, please enter the required password (shown as **** on the screen).

2. Your Mobile Phone

Icons at the top

	New Text Message or inbox is full
	New MMS (Multi Media Message)
	Missed Call
	Call Divert
	Alarm Clock is On
	Ringtone will Vibrate and Ring
	Ringtone will just Ring
	Ringtone will Vibrate then ring
	Ringtone will vibrate only
	Headset mode
	New Service message
	Bluetooth is On
	nWay Stopwatch

3. Making and Receiving Calls

■ Making Calls

To make calls simply dial the number or choose the contact and press the press the Call button. Note: If you have more than one SIM card installed you will be asked which SIM slot you would like to use.

■ Receiving Call Log

To receive calls simply press the Call answer button.

4. Input Methods

■ Import Methods and Their Symbols

ABC	Complete capital letter typing.
abc	Complete lowercase typing.
PT/pt	Spanish/Portuguese typing.
ES/es	Spanish typing Capital and lowercase respectfully.
123	Number and symbol typing.

■ Changing the Input Method

In any typing function, press the “alt” key to change the input method.

5. Main Menu

Enter the main menu by pressing the Menu button.

6. Call Center

- **Call History**

  This will list all calls including: missed calls, dialed calls and answered calls, or you may enter the separate menus of missed calls, dialed calls and answered calls.

  You may select a call to: check details, delete, save, dial, edit, or to send a MMS or SMS to that person.

- **Call Settings**

  Call Waiting

  Once activated, you will be notified by the network in case of another incoming call when you are on a call. For specific usage, please get in contact with your network service provider. The following options are provided:

Call Diverting:

This service allows you to divert certain types of calls.

Line Switching:

This function allows you to switch between Line 1 and Line 2.

Black-list:

Calls from numbers in the blacklist will be blocked.

Auto Redial:

Choose On/Off to activate or turn off the function.

IP Dial:

You may edit number and can activate or deactivate it, if you activate it; you may IP dial-up.

Call Time Reminder:

This will give a sound reminder every minute during calls so that you know how long the call has lasted.

Answer Mode:

You may select different options. Set to you preference.

8. Fun & Games

- **Games**

Jigsaw Puzzle

Move small pieces of the picture with direction keys to restore a picture.

9. Extras

- **Tasks**

This will remind you of any tasks to be completed on a specific date or time.

- **Stopwatch**

Select common stopwatch or nWay stopwatch for timing.

- **File Manager**

Phone & memory card

You can create a data file folder, change a folder name, delete a folder, arrange files, and format the memory card and etc.

Send: For music files, you can set any one to be the ring tone of incoming calls. For pictures, you may set any one to be the wallpaper, screen saver or on/off display. For different functions, you may operate following the prompts on the screen.

Rename: Change the name of a file or file folder.

Copy a file: allows you to copy any file on the memory card.

Move: Allows you to move any file on the memory card.

- **Calculator**

  Use the calculator for adding, subtracting, multiplying and dividing. Press the keys of 0-9 to insert number and # to insert a decimal point. Press OK to get the result.

- **Alarm**

  Set the time of alarm clock, ring tone, ring mode, alarm ring mode and interval between repeated alarm rings at the time of the alarm.

- **E-book Reader**

  With this function, you may read any file in TXT format saved in the memory card. You just have to copy the file to the folder labeled [eBook] in the memory card

10. Multimedia

- **Camera**

  In the camera options, you can set the picture mode, exposure compensation, avoidance of flickering, postponing shooting, white balance, photo quality, photo size, special effect, profile and etc. You may enter the album to check the formats that the phone supports.

- **Video Recorder**

  In video camera options you can set the exposure compensation, avoidance of flickering, white balance, special effect, profile and etc.

- **Video Player**

  Choose from files saved on your memory card.

- **Audio Player**

  The music player is used to play music files. You may view details of the music files and set the current music file as the ring tone for incoming calls.

- **Sound Recorder**

  You can set a format for recording, and play back the recorded file.

- **FM Radio**

  This function allows you to listen to the radio. Simply turn it on and use the directional keys of left and right to manually tune the channel. In the options menu, you can choose manually or automatically search for channels and turn off background play.

11. Phonebook

You can save contact details including names and telephone numbers in the phonebook, which can store up to 500 entries. The number of contacts that can be stored on the SIM card depends on the type of the SIM card.

- **Search**

  Quick search: Allows you to quickly search for a desired contact.

- **Settings**

Preferred location for saving

You can choose your preferred location for saving phone numbers. You can choose between either the SIM card or phone.

Speed dial

This function enables you to press a numeric key to quick dial one of the corresponding preset telephone numbers.

12. Messaging

- **SMS (Standard Text Messages)**

  You can check all sent and received messages from Messages menu.

  Write a message: Select this to send messages. You may select multiple contacts to send the message to, 10 contacts is the maximum.

  Inbox: When you receive a message, enter the inbox to read it.

  Delete: Choose this to delete a message in the Inbox.

- **MMS (Multi Media Messaging)**

  This feature allows you to send pictures, videos, or music in an MMS message. You may also send the MMS to any email address or any cell phone number. If the MMS size is oversized, the cell phone may fail to send or receive it.

  Note: Consult with the local service provider for details about MMS sending and receiving restrictions.

- **Broadcast message**

  Cellular broadcasting is a network service provided for you to receive different types of information. Refer to your service provider for details.

13. Image Viewer

This feature allows you to view the photos saved on your phone and your memory card.

14. Calendar

The calendar feature reminds you of any tasks and memos for a certain date. You may view the calendar by week or month.

15. Services

- **Internet service**

  You may surf on-line with the WAP browser.

  For coverage details contact your service provider.

16. Settings

- **Volume Settings**

  You may customize these profiles and activate them at your own preference. In this menu you can set ring tones, ringing modes, and adjust all other audio options.

- **Phone Settings**

  This allows you to adjust current city, time format, display language and response time, and reset all settings.

- **Display Settings**

  This allows you to adjust the main wallpaper, screen saver, date/time, and the main screen icons.

- **Security Settings**

  This function allows you to keep your phone safe and locked. tThe default password is: "**0000"**

- **Connectivity**

  1) Bluetooth

  This allows you to establish wireless connections with other compatible Bluetooth devices. With Bluetooth you can send images, videos, music files between compatible devices.

2) Data account

These data accounts are the preset APN settings. In this menu you can add or remove data accounts.

- **Restore Factory Settings**

Enter the phone password your to reset your phone back to its factory settings.

The default password is: "**0000"**

17. Social Networks

- **Facebook**

Facebook is a social networking website that is operated and privately owned by Facebook, Inc. Users can add friends, send them messages, and update their personal profiles.

- **MSN**

MSN is a chat tool developed by Microsoft. It's commonly used throughout the world. You may chat with others via MSN Messenger.

18. SIM Cards

Your SIM card may provide several additional services like adding the capability of checking account balances and account settings.

NOTE: Not all SIM cards will provide this service. For more information, please contact your SIM cards service provider.

19. PC Connection

■ USB

Use the SD Memory card inserted in the phone as a Mass Storage Device (U-Disk) by simply connecting it to your computer via the supplied USB Cable. On the Phones Screen select “Mass Storage” and now you can transfer music, videos, games and other files from you phone to your computer and vice versa.

■ COM PORT

The COM port establishes a modem on your computer. The Serial Code is “*99#”.

20. Original Parts

Contact Social™ for supply of original parts. Here are some precautions you can take to keep the phone in good condition:

1. Keep the phone out of children's reach.
2. Regularly check the mobile equipment in your car to see whether it is correctly installed and are working normally.

Only use batteries, chargers and accessories approved by the Social™. Use of other types of batteries, chargers and accessories may cause damage to the phone and will result in a voided warranty.

21. About the Battery

- **Usage and Treatment of Battery**

  Avoid short circuits of the battery by keeping it away from water.

- **Do NOT Attempt to Take Apart the Battery;**

  Stop using the battery if the outer case is damaged!

  Return defective and used batteries to the supplier or an authorized dump site. Do not throw it away in the garbage.

22. Maintenance and Service

The following are some suggestions for you to effectively maintain the phone.

1. Keep the equipment dry.
2. Do not expose the phone to overheated locations.
3. Open the battery compartment as per the descriptions in the manual.
4. Do not throw, knock or shake the phone. Any rough treatment of the equipment may result in damage of the inner motherboard.
5. Do not clean the phone with ardent chemical, detergent or any other type of hazardous chemicals.
6. Clean the screen and camera lens with a clean, dry soft cloth.
7. Please use the charger indoors.

The above suggestions also apply to your battery, charger and other accessories.

23. Important Safety Directions

Medical Equipment

Operation of radio transmitting equipment (including wireless phones) may interfere with the functioning of medical equipment. For any questions or in the case you are not certain whether the medical equipment can shield the external RF waves please refer to the doctor or the manufacturer of the medical equipment. Turn off the mobile equipment as per any written requirements.

Planes

Do not use the phone when on a plane; please power off the equipment before boarding. Using mobile phones may result in interference to the operation of the plane.

Emergency Call

Like other wireless phones, this phone uses a radio signal. Thus, it is not guaranteed that the call can be put through in all circumstances. Therefore, it is not suggested to rely on any wireless equipment for important calls, such as medical treatment and first-aid.

Making Emergency Phone Calls:

1. First turn on the equipment and check for a network signal. In certain networks, it may be required to insert the valid SIM card.

Standard Limited Warranty

What is Covered and For How Long? SOCIAL MOBILE TELECOMMUNICATIONS warrants to the original purchaser ("Purchaser") that SOCIAL MOBILE TELECOMMUNICATION's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone: 90 days from purchase date

Batteries: 90 days from purchase date

Other Phone Accessories: 90 days from purchase date

What is Not Covered? This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, neglect, unusual physical, electrical or electromechanical stress, or defects in appearance, cosmetic, decorative or structural items, including framing, and any non-operative parts unless caused by SOCIAL MOBILE TELECOMMUNICATIONS; (b) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen; (c) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (d) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (e) malfunctions resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or

approved by SOCIAL MOBILE TELECOMMUNICATIONS; (f) defects or damage from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SOCIAL MOBILE TELECOMMUNICATIONS; (g) defects or damage from external causes such as collision with an object, or from fire, flooding, sand, dirt, windstorm, lightning, earthquake, or from exposure to weather conditions, or battery leakage, theft, blown fuse, or improper use of any electrical source; (h) defects or damage caused by cellular signal reception or transmission, or viruses or other software problems introduced into the Product; (j) any other acts which are not the fault of SOCIAL MOBILE TELECOMMUNICATIONS; or

(i) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SOCIAL MOBILE TELECOMMUNICATIONS for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SOCIAL MOBILE TELECOMMUNICATIONS phone for which it is specified.

Note: Original proof of purchase is required for any warranty claims

Please send all warranty or information requests to support@socialmobilecellular.com

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: FB101 (FCC ID:Z6RSMFB101) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.742W/kg and when properly worn on the body is 0.743W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar

Accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user’s authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant topart 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.